



# MICROWAVE OVEN

## INSTRUCTION MANUAL

AW925EBL-S10E

SAVE THESE INSTRUCTIONS CAREFULLY !



Customer centre	Carrier Midea India Private Limited 1st Floor, Pearl Tower, Plot No. 51, Sector 32, Gurgaon, Haryana 122001, INDIA
Contact No.	1800301111111, 312111111
E-mail	customersupport.india@carrier.utc.com
Website	www.carriermideaindia.com

Read these instructions carefully before using your microwave oven, and keep it carefully. If you follow the instructions, your oven will provide you with many years of good service.

## PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do not attempt to operate this oven with the door open since this can result in harmful exposure to microwave energy. It is important not to break or tamper with the safety interlocks.
- (b) Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- (c) **WARNING:** If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.

## ADDENDUM

If the apparatus is not maintained in a good state of cleanliness, its surface could be degraded and affect the lifespan of the apparatus and lead to a dangerous situation.

## Specifications

Model:	AW925EBL-S10E
Rated Voltage:	230V~50Hz
Rated Input Power(Microwave):	1500W
Rated Output Power(Microwave):	900W
Rated Input Power(Grill):	1400W
Rated Input Power(Convection):	2400W
Oven Capacity:	25 L
Turntable Diameter:	Ø315mm
External Dimensions:	512mmX461mmX306.5mm
Net Weight:	Approx 17kg

# IMPORTANT SAFETY INSTRUCTIONS

## WARNING

To reduce the risk of fire, electric shock, injury to persons or exposure to excessive microwave oven energy when using your appliance, follow basic precautions, including the following:

1. **Warning:** Liquids and other foods must not be heated in sealed containers since they are liable to explode.
2. **Warning:** It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.
3. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
4. Keep the appliance and its cord out of reach of children less than 8 years.
5. Only use utensils suitable for use in microwave ovens.
6. The oven should be cleaned regularly and any food deposits should be removed.
7. Read and follow the specific: "PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY".
8. When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition.
9. If smoke is emitted, switch off or unplug the appliance and keep the door closed in order to stifle any flames.
10. Do not overcook food.
11. Do not use the oven cavity for storage purposes. Do not store items, such as bread, cookies, etc. inside the oven.
12. Remove wire twist-ties and metal handles from paper or plastic containers/bags before placing them in the oven.
13. Install or locate this oven only in accordance with the installation instructions provided.
14. Eggs in the shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended.
15. This appliance is intended to be used in household and similar applications such as:
  - staff kitchen areas in shops, offices and other working environments;
  - by clients in hotels, motels and other residential type environments;
  - farm houses;
  - bed and breakfast type environments.
16. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
17. Do not store or use this appliance outdoors.
18. Do not use this oven near water, in a wet basement or near a swimming pool.
19. The temperature of accessible surfaces may be high when the appliance is operating. The surfaces are liable to get hot during use. Keep cord away from heated surface, and do not cover any events on the oven.
20. Do not let cord hang over edge of table or counter.
21. Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.
22. The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.

23. Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container.
24. The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
25. Children should be supervised to ensure that they do not play with the appliance.
26. The appliances are not intended to be operated by means of an external timer or separate remote-control system.
27. Accessible parts may become hot during use. Young children should be kept away.
28. Steam cleaner is not to be used.
29. During use the appliance becomes hot. Care should be taken to avoid touching heating elements inside the oven.
30. Only use the temperature probe recommended for this oven. (for ovens provided with a facility to use a temperature-sensing probe.)
31. **WARNING:** The appliance and its accessible parts become hot during use. Care should be taken to avoid touching heating elements. Children less than 8 years of age shall be kept away unless continuously supervised.
32. The microwave oven must be operated with the decorative door open. (for ovens with a decorative door.)
33. The rear surface of appliance shall be placed against a wall.
34. The microwave oven shall not be placed in a cabinet unless it has been tested in a cabinet.

## **READ CAREFULLY AND KEEP FOR FUTURE REFERENCE**

# To Reduce the Risk of Injury to Persons

## Grounding Installation

### DANGER

#### Electric Shock Hazard

Touching some of the internal components can cause serious personal injury or death.

Do not disassemble this appliance.

### WARNING

#### Electric Shock Hazard

Improper use of the grounding can result in electric shock. Do not plug into an outlet until appliance is properly installed and grounded.

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

Consult a qualified electrician or serviceman if the grounding instructions are not completely understood or if doubt exists as to whether the appliance is properly grounded. If it is necessary to use an extension cord, use only a 3-wire extension cord.

1. A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
2. If a long cord set or extension cord is used:

1)The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.

2)The extension cord must be a grounding-type 3-wire cord.

3)The long cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over unintentionally.

### CLEANING

Be sure to unplug the appliance from the power supply.

1. Clean the cavity of the oven after using with a slightly damp cloth.
2. Clean the accessories in the usual way in soapy water.
3. The door frame and seal and neighbouring parts must be cleaned carefully with a damp cloth when they are dirty.
4. Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.
5. Cleaning Tip---For easier cleaning of the cavity walls that the food cooked can touch:  
Place half a lemon in a bowl, add 300ml (1/2 pint) water and heat on 100% microwave power for 10 minutes.  
Wipe the oven clean using a soft, dry cloth.

# UTENSILS

See the instructions on "Materials you can use in microwave oven or to be avoided in microwave oven."

There may be certain non-metallic utensils that are not safe to use for microwaving. If in doubt, you can test the utensil in question following the procedure below.

## CAUTION

### Personal Injury Hazard

It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.

### Utensil Test:

1. Fill a microwave-safe container with 1 cup of cold water (250ml) along with the utensil in question.
2. Cook on maximum power for 1 minute.
3. Carefully feel the utensil. If the empty utensil is warm, do not use it for microwave cooking.
4. **Do not exceed 1 minute cooking time.**

## Materials you can use in microwave oven

Utensils	Remarks
Aluminum foil	Shielding only. Small smooth pieces can be used to cover thin parts of meat or poultry to prevent overcooking. Arcing can occur if foil is too close to oven walls. The foil should be at least 1 inch (2.5cm) away from oven walls.
Browning dish	Follow manufacturer's instructions. The bottom of browning dish must be at least 3/16 inch (5mm) above the turntable. Incorrect usage may cause the turntable to break.
Dinnerware	Microwave-safe only. Follow manufacturer's instructions. Do not use cracked or chipped dishes.
Glass jars	Always remove lid. Use only to heat food until just warm. Most glass jars are not heat resistant and may break.
Glassware	Heat-resistant oven glassware only. Make sure there is no metallic trim. Do not use cracked or chipped dishes.
Oven cooking bags	Follow manufacturer's instructions. Do not close with metal tie. Make slits to allow steam to escape.
Paper plates and cups	Use for short-term cooking/warming only. Do not leave oven unattended while cooking.
Paper towels	Use to cover food for reheating and absorbing fat. Use with supervision for a short-term cooking only.
Parchment paper	Use as a cover to prevent splattering or a wrap for steaming.
Plastic	Microwave-safe only. Follow the manufacturer's instructions. Should be labeled "Microwave Safe". Some plastic containers soften, as the food inside gets hot. "Boiling bags" and tightly closed plastic bags should be slit, pierced or vented as directed by package.
Plastic wrap	Microwave-safe only. Use to cover food during cooking to retain moisture. Do not allow plastic wrap to touch food.
Thermometers	Microwave-safe only (meat and candy thermometers).
Wax paper	Use as a cover to prevent splattering and retain moisture.

## Materials to be avoided in microwave oven

Utensils	Remarks
Aluminum tray	May cause arcing. Transfer food into microwave-safe dish.
Food carton with metal handle	May cause arcing. Transfer food into microwave-safe dish.
Metal or metal-trimmed utensils	Metal shields the food from microwave energy. Metal trim may cause arcing.
Metal twist ties	May cause arcing and could cause a fire in the oven.
Paper bags	May cause a fire in the oven.
Plastic foam	Plastic foam may melt or contaminate the liquid inside when exposed to high temperature.
Wood	Wood will dry out when used in the microwave oven and may split or crack.


## SETTING UP YOUR OVEN

### Names of Oven Parts and Accessories

Remove the oven and all materials from the carton and oven cavity.


Your oven comes with the following accessories:

Glass tray	1
Turntable ring assembly	1
Instruction Manual	1



Grill Rack( Only be used in grill function and be placed on the glass tray )

## Turntable Installation



- Never place the glass tray upside down. The glass tray should never be restricted.
- Both glass tray and turntable ring assembly must always be used during cooking.
- All food and containers of food are always placed on the glass tray for cooking.
- If glass tray or turntable ring assembly cracks or breaks, contact your nearest authorized service center.

## Countertop Installation


Remove all packing material and accessories. Examine the oven for any damage such as dents or broken door. Do not install if oven is damaged.

**Cabinet:** Remove any protective film found on the microwave oven cabinet surface.

**Do not remove the light brown Mica cover that is attached to the oven cavity to protect the magnetron.**

## Installation

- Select a level surface that provide enough open space for the intake and/or outlet vents.



- The minimum installation height is 85cm.
- The rear surface of appliance shall be placed against a wall. Leave a minimum clearance of 30cm above the oven, a minimum clearance of 20cm is required between the oven and any adjacent walls.
- Do not remove the legs from the bottom of the oven.

- Blocking the intake and/or outlet openings can damage the oven.
- Place the oven as far away from radios and TV as possible. Operation of microwave oven may cause interference to your radio or TV reception.
- Plug your oven into a standard household outlet. Be sure the voltage and the frequency is the same as the voltage and the frequency on the rating label.

**WARNING:** Do not install oven over a range cooktop or other heat-producing appliance. If installed near or over a heat source, the oven could be damaged and the warranty would be void.



The accessible surface may be hot during operation.





# Rotisserie Skewer Installation

After putting the food on the rotisserie skewer, firstly, connection part 1 of the rotisserie skewer should be aimed at the shaft of the rotary motor. Then the shaft is put into the hole of the connection part. Secondly, put the supporting part 2 of the rotisserie skewer to the upside of the rotisserie skewer which is on the profile of the cavity. There is a semicircular position in the middle of the supporting part, the food can be put on it.



**Warning: using the rotisserie skewer under microwave is forbidden.**

# OPERATION INSTRUCTION


This microwave oven uses modern electronic control to adjust cooking parameters to meet your needs better for cooking.

## 1. Clock Setting

When the microwave oven is electrified, the oven will display "0:00", buzzer will ring once.

1) Press " **CLOCK/KITCHEN TIMER** " once. "00:00" displays.


---

2) Turn "  " to adjust the hour figures, the input time should be within 0--23(24-hour).

---

3) Press " **CLOCK/KITCHEN TIMER** ", the minute figures will flash.

---

4) Turn "  " to adjust the minute figures, the input time should be within 0--59.

---

5) Press " **CLOCK/KITCHEN TIMER**" to finish clock setting. ":" will flash.


**Note:** 1) If the clock is not set, it would not function when powered.

2) During the process of clock setting, if you press " **STOP/CLEAR** ", the oven will go back to the previous status automatically.

## 2. Kitchen Timer

(1) Press " **CLOCK/KITCHEN TIMER** " twice, LED will display 00:00.

---

(2) Turn "  " to enter the correct timer.(The maximum cooking time is 95 minutes.)

---

(3) Press " **START/+30SEC./CONFIRM** " to confirm setting.


(4) When the kitchen time is reached, the buzzer will ring 5 times.


If the clock be set(24-hour system), LED will display the current time.

Note: The kitchen Time is differ from 24-hour system,Kitchen Timer is a timer.

## 3. Microwave Cooking

Press " **Microwave** " the LED will display "P100".Press " **Microwave** " for times


or turn "  "to choose the power you want, and "P100", "P80" "P50", "P30" or

"P10" will display for each added press. Then press " **START/+30SEC./CONFIRM** " to confirm, and turn "  " to set cooking time. Press " **START/+30SEC./CONFIRM** " again to start cooking.

Example: If you want to use 80% microwave power to cook for 20 minutes, you can operate the oven as the following steps.

- 1) Press "**Microwave**" once, the screen display "P100".


---

- 2) Press "**Microwave**" once again or turn " " to choose 80% microwave power.

---

- 3) Press "**Start/+30Sec./Confirm**" to confirm, and the screen displays "P 80".

---

- 4) Turn " " to adjust the cooking time until the oven displays "20:00".

---

- 5) Press "**Start/+30Sec./Confirm**" to start cooking .



**NOTE:** the step quantities for the adjustment time of the coding switch are as follow:

0---1 min	:	5 seconds
1---5 min	:	10 seconds
5---10 min	:	30 seconds
10---30 min	:	1 minute
30---95 min	:	5 minutes

#### Microwave Power Chart

Press	Once	Twice	Thrice	4 times	5 times
Microwave Power	100%	80%	50%	30%	10%

## 4. Grill or Combi. Cooking

Press "**Grill/Combi.**" the LED will display "G-1", and press "**Grill/Combi.**" for times or turn the " " to choose the power you want, and "G-1", "C-1", "C-2", "C-3" or "C-4" will display for each added press. Then press "**Start/+30Sec./Confirm**" to confirm, and turn " " to set cooking time. Press "**Start/+30Sec./Confirm**" again to start cooking.


Example: If you want to use grill power to cook for 10 minutes, you can operate the oven as the following steps.

- 1) Press "**Grill/Combi.**" once, the screen display "G-1".

---

- 2) Press "**Start/+30Sec./Confirm**" to confirm.

---

- 3) Turn " " to adjust the cooking time until the oven displays "10:00".


---

- 4) Press "**Start/+30Sec./Confirm**" to start cooking .

**Note:** If half the grill time passes, the oven sounds twice, and this is normal. In order to have a better effect of grilling food, you should turn the food over, close the door, and then press "**START/ +30SEC./ Confirm**" to continue cooking. If no operation, the oven will continue working.

## 5. Convection Cooking(With preheating funtion)


The convection cooking can let you to cook the food as a traditional oven. Microwave is not used. It is recommended that you should preheat the oven to the appropriate temperature before placing the food in the oven.

- 1) Press the "**CONVECTION**" key once, "150" flash.
- 2) Keep pressing "**CONVECTION**" or turn " " to select the convection function.

Note:the temperature can be chosen from 150 degrees to 240 degrees.

---

- 3) Press the "**START/+30SEC./CONFIRM**" to confirm the temperature.
  - 4) Press the "**START/+30SEC./CONFIRM**" to start preheating.When the preheating temperature arrives, the buzzer will sound twice to remind you to put the food into the oven. And the preheated temperature is displayed and flash.
- 

- 5) Put the food into the oven and close the door.  
Turn " " to adjust the cooking time. (The maximum setting time is 95 minutes.)
- 


- 6) Press the "**START/+30SEC./CONFIRM**" key to start cooking.

Note: a. Cooking time cannot be input until the preheating temperature arrives.

If the temperature arrives, door must be opened to input the cooking time.


- b. If the time not input in 5 minutes, the oven will stop preheating. The buzzer sound five times and turn back to waiting states.

## 6. Convection Cooking( Without pre-heating function)

- 1) Press the "**CONVECTION**" key once, "150" flash.
- 2) Keep pressing "**CONVECTION**" or turn " " to select the convection function.

Note:the temperature can be chosen from 150 degrees to 240 degrees.

---




- 3) Press the "**START/+30SEC./CONFIRM**" to confirm the temperature
  - 4) Turn " " to adjust the cooking time. (The maximum setting time is 95 minutes.)
  - 5) Press the "**START/+30SEC./CONFIRM**" key to start cooking.
-

## 7. Multi-Stage Cooking

Two stages can be maximumly set. If one stages is defrosting, it should be put in the first stage. The buzzer will ring once after each stage and the next stage will begin.

**Note:** Auto menu and preheating cannot be set as one of the multi-stage.

Example: if you want to defrost the food for 5 minutes, then to cook with 80% microwave power for 7 minutes. The steps are as following:


- 1) Press "**W.T./TIME DEFROST**" twice, the screen will display "d-2";
- 2) Turn " " to adjust the defrost time of 5 minutes;
- 3) Press "**MICROWAVE**" once;
- 4) Turn " " to choose 80% microwave power till "P80" display;
- 5) Press "**START/+30SEC./CONFIRM**" to confirm;
- 6) Turn " " to adjust the cooking time of 7 minutes;
- 7) Press "**START/+30SEC./CONFIRM**" to start cooking.

## 8. Speedy Cooking



- 1) In waiting state, press "**START/+30SEC./CONFIRM**" key to cook with 100% power level for 30 seconds. Each press on the same key can increase 30 seconds. The maximum cooking time is 95 minutes.
- 2) During microwave, grill, convection and combination states, press "**START/+30SEC./CONFIRM**" key to cook with 100% power level for 30 seconds. Each press on the same key can increase 30 seconds.

**Note:** this function cannot work under weight defrost, multi-stage and auto menu cooking.

## 9. Speedy Microwave Cooking

In waiting state, turn " " left to choose cooking time directly then press "**START/+30SEC./CONFIRM**" key to cook with 100% microwave power. This program can be set as one of multi-stage.


## 10. Auto Menu

- 1) In waiting state, turn " " right to choose the function wanted, and "A001", "A002", "A003"... "A120" will be displayed.
- 2) Press "**START/ +30 SEC./CONFIRM**" to confirm the menu you need.
- 3) Turn " " to choose the weight of menu.
- 4) Press "**START/ +30 SEC./CONFIRM**" to start cooking.

## 11. Defrost by W.T.

- 1) Press "**W.T./TIME DEFROST**" pad once, the oven will display "d-1",.

---

- 2) Turn " " to select the weight of food. At the same time, "g" will light, The weight should be 100-2000g.


---

- 3) Press "**START/+30SEC./CONFIRM**" key to start defrosting.

## 12. Defrost by Time

- 1) Press "**W.T./TIME DEFROST**" key twice, the oven will display "d-2"

---

- 2) Turn " " to select the cooking time. The maximum setting time is 95 minutes.


---

- 3) Press "**START/+30SEC./CONFIRM**" key to start defrosting.

## 13. Inquiring Function

- (1) During cooking state, press "**CLOCK/KITCHEN TIMER**" to check the current time. It will be displayed for 2-3 seconds.
- (2) In cooking state, press "**MICROWAVE**", "**GRILL/ COMBI.**" or "**CONVECTION**", the current power will be displayed for 2-3 seconds.

## 14. Lock-out Function for Children

Lock: In waiting state, press "**STOP/CLEAR**" for 3 seconds, there will be a long "beep" denoting entering into the children-lock state and " " indicator will light. LED will display current time or 0:00.

Lock quitting: In locked state, press "**STOP/CLEAR**" for 3 seconds, there will be a long "beep" denoting that the lock is released, and " " indicator will disappear.

## 15. Specification

- (1) The buzzer will sound once when turning the knob at the beginning;
- (2) "**START/+30 SEC./CONFIRM**" must be pressed to continue cooking if the door is opened during cooking;
- (3) Once the cooking programme has been set, "**START/+30 SEC./CONFIRM**" is not pressed in 5 minutes. The current time will be displayed. The setting will be cancelled.
- (4) The buzzer sounds once by efficient press, inefficient press will be no response.
- (5) The buzzer will sound five times to remind you when cooking is finished.

Auto menu Chart

	Menu	weight	display
menu_1 Main Course	A1 Pepper Chicken	400g	400
	A2 Chilli Chicken	400g	400
	A3 Aloo Masala	200g	200
	A4 Baigan Masala	300g	300
	A5 Gobhi Masala	300g	300
	A6 Bhindi Masala	300g	300
	A7 Mutton Biryani	100g	100
	A8 Onion Rice	200g 300g	200 300
	A9 Dal	200g	200
	A10 Sambar	200g	200

menu_1 Main Course	A11 Muttor Paneer	300g	300
	A12 Aloo Gobhi	300g	300
	A13 Aloo Methi	300g	300
	A14 Jeera Aloo	300g	300
	A15 Karela Sabji	300g	300
	A16 Masala Arvi	300g	300
	A17 Masala Arbi	300g	300
	A18 Chole	200g	200
	A19 Rajma	200g	200
	A20 Kadhi	100g 200g 300g	100 200 300



menu_1 Main Course	A21 Mutton curry	100g	100
		200g	200
		300g	300
		400g	400
		500g	500
	A22 Spicychicken Masala	100g	100
		200g	200
		300g	300
		400g	400
		500g	500
	A23 Dosa Sabji	300g	300
	A24 Keema Masala	300g	300

menu_1 Main Course	A25 BaiganBharta	500g	500
menu_2 Health Plus	A26 Sprouts	250g	250
	A27 Chivda	250g	250
	A28 Corn Chat	250g	250
	A29 Lemon Chicken	400g	400
	A30 Garlic Chicken	100g	100
		200g	200
		300g	300
		400g	400
500g		500	
A31 Grilled Chicken	200g	200	

menu_2 Health Plus	A32 Tandoori Fish	200g	200
	A33 Muttontikka	500g	500
	A34 Ghiya Raita	250g	250
menu_3 Continental	A35 Pasta	200g	200
	A36 Macroni	300g	300
	A37 Baked Macaroni	100g	100
		200g	200
		300g	300
	A38 Grill Sandwich	1	1
		2	2
		4	4
	A39 Cheese Sandwich	1	1
		2	2
		4	4

menu_3 Continental	A40 Chicken Club Sandwich	1	1
		2	2
		4	4
	A41 Stuffed Sandwich	1	1
		2	2
		4	4
	A42 Veg Pizza	1	1
	A43 Chicken Pizz	1	1
	A44 Cheese Pizza	1	1
	A45 Onion Capcicum Pizza	1	1
menu_4 Sweet	A46 Gajar Ka Halwa	100g	100
		200g	200
		300g	300

menu_4 Sweet	A47 Ghiya Halwa	400g	400
		500g	500
	A48 Coconut Burfi	100g	100
		200g	200
		300g	300
	A49 Khoya Burf	100g	100
		200g	200
		300g	300
	A50 Kheer	100g	100
	A51 Coconut Kheer	300g	300
	A52 Suji Halwa	100g	100

menu_4 Sweet	A53 Pineapple Halwa	200g	200
		300g	300
	A54 Sweet Saviya	200g	200
	A55 Besan Ladoo	300g	300
	A56 Atta Ladoo	300g	300
	A57 Milk Cake	200g	200
	A58 Chicken Sweet Corn Soup	1 Bowl	1
menu_5 Baking	A59 Choco pudding	300g	300
	A60 Appam	300g	300
	A61 Nan Khatai	100g	100
		200g	200
		300g	300
A62 Brownie	500g	500	

menu_5 Baking	A63 3 in 1 Cake	500g	500
	A64 Choclate Cake	500g	500
	A65 Marble Cake	500g	500
	A66 Stawberry Cake	500g	500
	A67 Vanila Cake	500g	500
	A68 Truffle Cake	500g	500
	A69 Stawberry Cake	300g	300
	A70 Cookies	100g	100
	A71 Cheese Straw	200g	200
	A72 Salty Biscuits	300g	300
	A73 Pinwill Cookies	300g	300
	A74 Swiss Roll	300g	300
	A75 Chicken Sweet Corn Soup	1 Bowl	1

menu_6 Soups	A76 Sweet Corn Soup	1 Bowl	1
	A77 Tomato Soup	2 Bowl	2
	A78 Green Peas Soup	300g	300
	A79 Chicken soup	500g	500
	A80 Mushroom Soup	500g	500
menu_7 Sea Food	A81 Chilli Prawns	400g	400
	A82 Prawn masala curry	400g	400
	A83 Shrimps Curry	400g	400
	A84 Fish Curry	400g	400
	A85 King Fish Vindaloo	400g	400
menu_8 Snacks	A86 Murmurra Patti	200g	200
	A87 Noodles	500g	500



menu_8 Snacks	A88 Pav Bhajji	200g	200
	A89 Chicken Chowmin	100g	100
		200g	200
		300g	300
	A90 Aloo Tikki	100g	100
		200g	200
	A91 Grilled Veg	300g	300
		400g	400
		500g	500
	A92 Macchi Kalimirch	400g	400
	A93 Cheese Balls	100g	100
		200g	200
		300g	300

menu_8 Snacks	A94 French Fries	100g	100
		200g	200
		300g	300
		400g	400
		500g	500
	A95 Grilled Potato	100g	100

menu_8 Snacks	A96 Grilled Chciken Masala	300g	300
		400g	400
		500g	500
	A97 Chutney	250g	250
	A98 Fish tikka	400g	400
	A99 Baked Mushroom	400g	400
	A100 Grilled Paneer Tikka	100g	100
	A101 Cutlet	300g	300
	A102 Harabhara Kabab	400g	400

menu_9 Breakfast	A103 Aam Panna	6 Bowls	6
	A104 Tea	2 Cup	2
	A105 Coffee	2 Cup	2
	A106 Mix Fruit Jam/ Apple Jam	100g	100
		200g	200
	A107 Apple Jam	300g	300
		100g	100
		200g	200
		300g	300
	A108 Pineapple Jam	200g	200
	A109 Poha	250g	250

menu_9 Breakfast	A110 Rice Idli	100g	100
	A111 Rawa Idli	100g	100
	A112 Momos	200g	200
	A113 Daliya	200g	200
	A114 Pongal	200g	200
	A115 Omlet	2 Eggs	2
	A116 Upma	200g	200
		300g	300
400g		400	

menu_9 Breakfast	A117 Uppti	200g	200
		300g	300
		400g	400
	A118 Garlic Bread	1	1
	A119 Bread	1	1
menu_10 reheat	A120 reheat	150g	150
		250g	250
		350g	350
		450g	450
		600g	600

## Trouble shooting

<b>Normal</b>	
Microwave oven interfering TV reception	Radio and TV reception may be interfered when microwave oven operating. It is similar to the interference of small electrical appliances, like mixer, vacuum cleaner, and electric fan. It is normal.
Dim oven light	In low power microwave cooking, oven light may become dim. It is normal.
Steam accumulating on door, hot air out of vents	In cooking, steam may come out of food. Most will get out from vents. But some may accumulate on cool place like oven door. It is normal.
Oven started accidentally with no food in.	It is forbidden to run the unit without any food inside. It is very dangerous.

<b>Trouble</b>	<b>Possible Cause</b>	<b>Remedy</b>
Oven can not be started.	(1) Power cord not plugged in tightly.	Unplug. Then plug again after 10 seconds.
	(2) Fuse blowing or circuit breaker works.	Replace fuse or reset circuit breaker (repaired by professional personnel of our company)
	(3) Trouble with outlet.	Test outlet with other electrical appliances.
Oven does not heat.	(4) Door not closed well.	Close door well.
Glass turntable makes noise when microwave oven operates	(5) Dirty roller rest and oven bottom.	Refer to "Maintenance of Microwave" to clean dirty parts.



**According to Waste of Electrical and Electronic Equipment (WEEE) directive, WEEE should be separately collected and treated. If at any time in future you need to dispose of this product please do NOT dispose of this product with household waste. Please send this product to WEEE collecting points where available.**